Assembly Instructions 43313587 OUTDOOR SUN LOUNGER

CARE INSTRUCTIONS: WIPE CLEAN WITH A SOFT CLOTH. DO NOT USE ABRASIVE MATERIALS AND SOLVENTS. STORE IN A DRY PLACE. SPOT CLEAN WITH WARM SOAPY WATER IF REQUIRED. DO NOT BLEACH OR USE HARSH CHEMICALS. DRY FLAT IN SHADE. DO NOT BLEACH. DO NOT TUMBLE DRY. DO NOT DRYCLEAN. DRY THOROUGHLY BEFORE STORAGE. WHEN NOT IN USE. THIS ITEM SHOULD BE STORED AWAY.

WARNING: DO NOT STAND ON THE LOUNER. DO NOT USE THE LOUNGER AS A STEP LADDER. SUITABLE FOR ONE PERSON USE ONLY. DO NOT FULL TIGHTEN ALL SCREWS UNTIL ALL HAVE BEEN COMPLETED. DO NOT USE THIS UNIT UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED. ADULT ASSEMBLY REQUIRED. ONLY USE ON EVEN AND FLAT SURFACE. FOR DOMESTIC USE ONLY. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

MAXIMUM SAFE LOAD: 100KG.



