

# Assembly Instructions

**K:43329861 | T:68735586 PANELLED TOILET UNIT**



**CARE INSTRUCTION:** Wipe clean with a soft dry or damp cloth. Keep away from water and direct sunlight. For indoor and domestic use. Check and tighten all parts regularly.

**WARNINGS:** Do not stand or sit on the unit. Do not lean on the product. Do not drag the product. Use only on a flat surface. Do not use until all screws, bolts and knobs are firmly secured. This product contains small parts and sharp points, keep away from children and babies. Adult assembly required. Failure to follow these warnings could result in serious injury.

**MAXIMUM TOTAL LOADING WEIGHT:** 2KGS FOR EACH SHELF AND TOP BOARD, 6KGS IN TOTAL.



## Hardware list

	a		12PCS		j		1PC
	b		12PCS		k	4X16mm	1PC
	c	6X30mm	16PCS		l		6PCS
	d	3X12mm	9PCS		m	3X14mm	8PCS
	e		2PCS		n	4X12mm	1PC
	f		1PC		o	4X35mm	1PC
	g		1PC		p		1PC
	h		4PCS		q		1PC
	i		1PC		r		1PC




**DO NOT TIGHTEN THE SCREWS UNTIL THE PRODUCT IS FULLY ASSEMBLED.**


**STEP 1**




**STEP 2**





**STEP 3**




**STEP 4**





STEP 5





STEP 6




STEP 7



STEP 8





# STEP 9





# STEP 10

 X4





# STEP 11

 X4     X1





# STEP 12


 X5     X2     X1     X1     X1




**STEP 13**





**STEP 14**





**STEP 15**






**STEP 16**




## STEP 17



## STEP 18



## STEP 19



### Warning:

- It is strongly recommended that this product is permanently fixed to the wall.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Stability of tall items may be affected by thick pile carpet or uneven floors.

• Do not place unanchored televisions on cabinet.

Caution: for your safety when attaching the anchor fixings, please note the following:

- Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.

