

# Assembly Instructions


## 43351251 ZANDER LOUNGE CHAIR

**CARE INSTRUCTIONS:** WIPE CLEAN WITH A SOFT DAMP CLOTH. DO NOT USE ABRASIVE MATERIAL AND SOLVENTS. SPOT CLEAN IF NEEDED. STORE IN A DRY PLACE. CHECK AND TIGHTEN ALL PARTS REGULARLY. FOR INDOOR AND DOMESTIC USE.


**WARNING:** DO NOT STAND ON THE CHAIR. USE ONLY ON A FLAT SURFACE. DO NOT USE UNTIL ALL SCREWS, BOLTS AND KNOBS ARE FIRMLY SECURED. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

**MAXIMUM SAFE LOAD: 100KG.**


Ax1



Cx6





Bx6




Feet tied with red rope in the carton


Dx6



## STEP 1



## STEP 2



If the chair is not smooth after assembly, please use the part D to stick on the bottom of the foot to level.