

Mini Light Up Easel



Input power: USB 5V 1A.

Light color: 2700-3000K Warm yellow

INCLUDES:

1 x adjustable support

1x transparent drawing board with USB

7 x easy clean markers



ASSEMBLY METHOD:



Open the multi-function adjustable support.



Adjust the tilt of base and back of multi-function adjustable support.



Secure the drawing board on the bottom slot of the multi-function adjustable easel.

WARNING:

This toy is only to be connected to equipment bearing either of the following symbols:



- The transformer, power supply or battery charger used with the electric toy shall be regularly examined for damage to the supply cord, pluy, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.
- The toy shall ony be used with a transformer for toys or a power supply for toys. (DC: 5V 1A)
- The transformer or power supply is not a toy.
- The instruction must be retained since it contains important information.

CAUTIONS:

- 1. It's easier to erase the text and drawing when the ink is dried.
- 2. Keep the product away from water source.
- 3. Keep away from high temperature and humid conditions.
- 4. Keep this product out of reach of small children.
- 5. Do not pull the power cord.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD

CAUTION: RINSE EYES IMMEDIATELY IF THE MARKER INK COMES INTO CONTACT WITH THEM, IF IRRITATION PERSISTS, SEEK MEDICAL ATTENTION.

WARNING:
CHOKING HAZARD - SMALL PARTS.
NOT FOR CHILDREN UNDER 3 YEARS.

ATTENTION: ALL ART MATERIALS LIKE PAINT, MAY CAUSE STAINS, ALWAYS PROTECT CLOTHES, CARPET, WORK SURFACE, FURNITURE AND OTHER OBJECTS, ALWAYS USE A PROTECTIVE COVER TO PREVENT STAINS.

ADULT SUPERVISION REQUIRED PRODUCT MAY VARY FROM THE IMAGE SHOWM. PLEASE KEEP PACKGING FOR FUTURE REFERENCE.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567

