


ASSEMBLY INSTRUCTION


K:43-472-772 | T:70-208-412
EXTENDABLE DISH RACK

STEP 1




Unfold the six supporting feet at the bottom of the tray. Ensure all feet are securely extended to provide stability.

STEP 2




Place the iron rack onto the tray and insert the cutlery caddy onto the iron rack. Ensure all parts fit snugly into place to provide a stable surface for drying dishes and cutlery.

STEP 3



Tray is extendable to hold more dishes when needed.

STEP 4



Turn to unlock the draining spout underneath the tray.