


Supermarket Scanner

3+



ON/OFF & SCAN (K#05)

When the unit is in OFF status, press K#05 to turn ON the unit.
 When the unit is in ON status, long press K#05 for 3 seconds to turn OFF the unit.
 When the unit is in ON status, press K#05 for scanning items. (The scanning function is same as K#07)

SCAN AND COUNT (K#01)

Press K#01 to enter the scan and count mode.
 Press K#05 or K#07 to scan different groceries and generate a random amount on screen.

SHOPPING LIST (K#02)

Press K#02 to enter the shopping list mode and will display the total amount on screen.
 Press K#04 to check out, press K#06 to exit check out.
 Shopping lists store up to 50 scanned items.

CLEAR THE SHOPPING LIST (K#03)

Press K#03 to enter the clear shopping list mode and will display the total amount on screen.
 Press K#04 to confirm clear, press K#06 to exit clear mode.

SLEEP MODE

If no key response / scan in 100 seconds, the unit will enter sleep mode.

▲ WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED BY AN ADULT. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

▲ WARNING: CHOKING HAZARD
 SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

▲ WARNING:
 DISPOSE OF USED BATTERIES IMMEDIATELY. KEEP NEW AND USED BATTERIES AWAY FROM CHILDREN.

▲ CAUTION: BATTERY INSTALLATION BY AN ADULT IS REQUIRED.

▲ WARNING:
 FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

MADE IN CHINA

CUSTOMER SERVICE:
 KMART AU: 1800 124 125
 KMART NZ: 0800 945 995
 TARGET AU: 1300 753 567

ADULT SUPERVISION REQUIRED.
 PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN.
 PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.
 INCLUDED BATTERIES ARE FOR IN STORE DEMONSTRATION PURPOSES ONLY. 43-473-243