






# Wooden Mega Busy Board House


## Assembly Instruction

K: 43494842 | T: 70392036


HARDWARE	PARTS LIST
<p><b>A</b>  x20</p> <p>Tools Required (Not Included)</p> <p> Cross screwdriver</p>	 <p>Diagram showing parts: a (x1), b (x1), c (x1), d (x1), e (x1), f (x1), g (x1), h (x1). Part h includes geometric shapes: a triangle, a cylinder, a star, and a hexagon.</p>
<p><b>CAUTION:</b> ADULT ASSEMBLY AND SUPERVISION REQUIRED.</p> <p><b>WARNING:</b> UNASSEMBLED PARTS CONTAIN SCREWS WITH FUNCTIONAL SHARP POINTS, PLEASE KEEP UNASSEMBLED PARTS AWAY FROM SMALL CHILDREN.</p> <p><b>CAUTION:</b> PLEASE CHECK CONDITION OF ITEM REGULARLY, AS SCREWS MAY LOOSEN WITH USE OVER TIME. TIGHTEN SCREW FITTINGS IF NECESSARY. STOP USING THIS PRODUCT IF THERE IS ANY LOOSE OR MISSING FASTENERS, JOINTS OR BROKEN PARTS.</p> <p><b>WARNING:</b> NOT SUITABLE FOR CHILDREN UNDER 18 MONTHS. LONG CORD. STRANGULATION HAZARD.</p> <p><b>WARNING:</b> FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.</p> <p>MADE IN CHINA</p> <p>READ AND FOLLOW INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE.</p>	<p><b>ASSEMBLY</b></p>
	<p><b>Step 1</b></p> 

# ASSEMBLY


## Step 2




## Step 3




## Step 4



## Step 5



## Step 6



## Step 7

