KMT说明书 折页 128g双铜 尺寸: 89*127mm

12 month warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurredin returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd.	Target Australia Pty Ltd
C/- Customer Service Centre	C/- Customer Service Centre
690 Springvale Road,	2 Kendall Street, Williams Landing,
Mulgrave Vic 3170	Vic, 3027
Customer Service: 1800 124 125	Customer Service: 1300 753 567
(Australia) or 0800 945 995	or via Customer Help at
(New Zealand) or via	target.com.au/help/contact-us
Customer Help at kmart.com.au	

anko

K: 43-498-963 | T: 70-361-445 Model: PW502

Wireless Charging Pad With Stand


User manual

Package contents:

- USB-C cable
- User manual



Function overview:



Specifications:

- Input: 5V=2A; 9V=2A

Output power: For iPhone: 5W/7.5W;
 For Android: 5W/7.5W/10W/15W(For some devices only)
 Transmission distance: 8mm

- Charging efficiency: 73%
 Material: ABS + zinc alloy

Operation Instruction

1.Connect the included cable to the power adapter with a rating of 18W or higher power and plug it into the power supply.

Note: 18W power adapter is not included.

- 2.Place the phone, which supports magnetic charging, onto the wireless charger. The charger will automatically align with the phone and charge it through magnetic
- 3. Ensure the center of the phone is aligned with the center of the wireless charger for optimal charging. If charging does not start, adjust the phone's position until it shows that charging is normal



Warning:

- 1. This product features input over-current and over-voltage protection. If it malfunctions or reduces output power, check for any abnormal conditions or improper use.
- 2. Avoid placing the product in water, fire, or extreme temperatures (>40°C or <-20°C), and keep it out of reach of children.
- 3.Use a dry, soft cloth to clean the surface. Avoid using chemicals, soap, or detergent.
- 4.Improper use or placement of this product may shorten its lifespan or cause damage, which is not covered under warranty. Please use the product as directed
- 5. The wireless charging efficiency may be affected by some phone cases. Make sure there is no metal foreign object between the charging pad and phone case when