anko

K: 43499069 | T:70362657 LED SOFT TOUCH LIGHT

- Please do not disassemble this product by yourself. When inspecting or repairing the lighting fixtures, seek professional advice to rectify the fault or make repairs.
- Do not position this light set where it will be exposed to wet condition or high temperature environment.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- To clean the lighting fixtures, the power must be turned off first, and the battery must be removed before proceeding with the cleaning operation.
- Do not wet the internal components of the product during cleaning.
- 6. Never mix different types or old and new batteries.
- 7. Do not short circuit supply terminals or dispose of batteries in fire.
- 8. Remove batteries during long time of non-use.
- 9. Indoor use only.

Operating instructions:

- 1. Open the battery cover at the bottom.
- 2. Install two 1.5V DC AAA batteries.
- Cover the cover and press the black button to turn on the light.Patting its body will change the color of the light, and pressing the black button will turn off the light.