

LIGHT UP STEPPING STONE INSTRUCTIONS

K: 43500086

WARNING! Assembly by an adult.

WARNING! Not suitable for children younger than 3 years old, contains small parts and have danger of falling.

WARNING! Use only under adult supervision. Do not use on a slippery or wet surface.

WARNING! Use on flat ground. Do not stand on the side of the product.

WARNING! Not suitable for children with a body mass of more than 50kg.



Instructions and package must be retained since it contains important information.

HOW TO LIGHT UP YOUR STEPPING STONE

Batteries not included. You need to prepare 3 X AA (1.5V) batteries for each piece of stepping stone. 9 X AA (1.5V) batteries needed for 1 set.

Step 1: Use tool(not provided) to loosen screws on battery compartment cover on underside of product and then release the cover.

Step 2: Insert/replace 3 X AA (1.5V) batteries as per the polarity diagram signified in the battery compartment.

Step 3: After batteries are inserted/changed, place the cover back onto the battery compartment and screw again to firmly secure the screws.

Step 4: Hold the power button to start. Step on the product to change colour. Hold the power button to stop.

Note: Lights will automatically off if no actions for 2 minutes. Step on the product to start again.

WARNINGS: Insert batteries with the correct polarity and always follow the manufacturer's instructions.

Do not mix new and used batteries or alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

Remove batteries if product will be stored for an extended period.

Dispose of used batteries responsibly.

Non-rechargeable batteries are not to be recharged.

Rechargeable batteries are only to be charged under adult supervision.

Exhausted batteries are to be removed from the toy.

The supply terminals are not to be short-circuited.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567