

anko

NAIL CLIPPERS WITH LED LIGHT



Contents




A



B

A. Nail clippers x 1pc	B. Screwdriver x 1pc
------------------------	----------------------

Each nail clippers requires
1 x 1.5V AAA battery(not included).



User manual

Step 1.

Use the screwdriver provided to open the battery compartment on the nail clippers. Insert 1 x AAA battery (not included).


Step 2.

Push switch down to unlock. Press the button to turn the LED light on.



Step 3.

Relax your pet and gently push one nail out. Use the light to find the bloodline and cut the nail just before. Refer to the image below



Optional: A mini nail file is included in the handle, use after trimming the nail to tidy up.



WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY. DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE NAIL CLIPPERS BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCULATED. REMOVE BATTERIES FROM THE PET NAIL CLIPPERS WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY ADULT REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.