SH005 - CrazyPets Can pack - IM

EN+ES

Diecut Line
Folding Line

Size : 116 x 60 mm / Double -side printing
Folded size : 58 x 60 mm

58 mm

60 mm

WWW.SHAKEHEADZ.COM

HOW TO PLAY

Remove the tab and turning the switch to ON position. Shake the Shakeheadz to make sound. The more you shake, the more it sounds.

Requires 3 "1.5 V AG13(LR44)" Batteries (Included)

CHANGING BATTERIES

Use a screwdriver to unscrew cover, note polarity of batteries, remove and replace with new ones as shown. Attach the cover and fasten screw. Never let a child use this product unless battery door is secure . Batteries are small objects and could be ingested. Keep all batteries away from small children.

0-3

Made in China

EN - WARNING: CHOKING HAZARD. Small parts. Not for children under 3 years. Please retain packaging for future references and remove all packacging attachments before giving product to child. Content may vary slightly from that shown on package.

Remove old batteries and replace with new batteries. Be sure to insert batteries correctly with adult supervision and always follow the toy and battery manufacturer's instructions. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Rechargeable batteries must be removed from toy before being recharged. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be charged only under adult supervision. ONLY use batteries specified by manufacturer. Do not short-circuit battery terminals. Always remove weak or dead batteries from product. Remove batteries if product will be stored for an extended period of time. Batteries should be changed by an Adult. Unscrew battery cover with phillips head screwdriver (not included) and lift away from back of product. Remove the dead batteries. Be sure to insert the new batteries correctly according to (+) and (–) symbols located on the battery compartment. Replace battery cover and tighten screw securely before further use.

WARNING!

Button cell batteries can cause serious injury or death if swallowed. Dispose of safely! Store batteries out of reach of children!

Visit TheBatteryControlled.com.au

Warning: Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Customer Label Position