

anko

Instruction manual

1. Product Specification

Input Power: DC 5V 2A

Remote control: CR2025 button cell battery

2. Accessories Quantities

1. Modular lights, double-adhesive tape, USB buckle x 6pcs, Fixing buckle x10pcs
2. remote control x 1
3. USB cable x 1

3. Instruction of Assembling and Using



1. Connect the USB buckle at "top" side with the modular at same direction.
2. Connect the USB buckle with the other light modular
3. Use the fixing buckle to fix the lamp shape
4. Connect the USB cable to a USB adapter (no included) with output voltage DC 5V 2A.
5. Remove the insulation tape on the remote control, press the "on" against the light. If the light is not on, please check the connector board whether is connected right.
6. Touch the center of each light to set the color of single light.
7. The other unoccupied USB port on the light can be used to power up.

Button cell battery warning

- SWALLOWING MAY LEAD TO SERIOUS INJURY OR DEATH IN AS LITTLE AS 2 HOURS DUE TO CHEMICAL BURNS AND POTENTIAL PERFORATION OF THE OESOPHAGUS.

- DISPOSE OF USED BATTERIES IMMEDIATELY AND SAFELY. FLAT BATTERIES CAN STILL BE DANGEROUS.

- EXAMINE DEVICES AND MAKE SURE THE BATTERY COM- PARTMENT IS CORRECTLY SECURED, E.G. THAT THE SCREW OR OTHER MECHANICAL FASTENER IS TIGHTENED. DO NOT USE IF COMPARTMENT IS NOT SECURE



WARNING: BUTTON CELL BATTERIES ARE HAZARDOUS (NEW OR USED). KEEP AWAY FROM CHILDREN. BUTTON CELL BATTERIES CAN CAUSE SEVERE OR FATAL INJURIES IN 2 HOURS OR LESS IF THEY ARE SWALLOWED OR PLACE INSIDE ANY PART OF THE BODY. IF YOU SUSPECT YOUR CHILD HAS SWALLOWED OR INSERTED A BUTTON CELL BATTERY, CALL THE 24-HOUR POISONS INFORMATION CENTRE IN AUSTRALIA ON 131126 OR IN NEW ZEAL AND 0800 764 766 OR CONTACT YOUR COUNTRY'S EMERGENCY DEPT. USED BATTERIES MUST BE DISPOSED OF IN THE GARBAGE OR A BATTERY RECYCLE FACILITY.

THIS PRODUCT CONTAINS
BUTTON CELL BATTERIES
SCAN THE QR CODE FOR
MORE INFORMATION .

Keep out of reach of children



205X142MM, 150G双面说明书1万张足数