

Kids Peanut Balance Ball

Keycode:43235919

Setup, Usage Tips, Care & Safety Guide

Please read before setting up and using this product.

TOOLS NEEDED


1. Pump (you may want to use a bicycle pump or compressor for initial inflation) not included with product.

SETUP

1. Remove the ball from box and check for shipping damage.
(Note: it is normal for balls to have slight creases or fold marks when first inflated.)
2. Allow ball to reach room temperature before inflating.
3. Insert tip of inflation needle into the hole in the ball (ensure tip is lubricated), inflate to desired height and firmness. DO NOT over inflate.
4. Remove pump from ball and immediately insert plug into hole (so head is flush with surface of ball).
5. To measure the correct inflation of your ball, please measure the diameter of the ball to 40cm as shown below.
6. Your Kids Peanut Balance Ball is now ready for use.

INFLATION NOTICE

- Inflate ball and plug.
- Ball may not inflate to 100% of size on initial inflation.
- Wait 24 hrs.
- Deflate 50% and inflate again.
- Due to the ball's material, the ball will increase to proper size with second inflation.



SIZE

Dia.40cm Ball with a peanut shape.



WARNING
CHOKING HAZARD
SMALL PARTS. NOT FOR
CHILDREN UNDER 3 YRS.

Kids Peanut Balance Ball

Keycode:43235919

Setup, Usage Tips, Care & Safety Guide

Please read before setting up and using this product.

IMPORTANT SAFETY CAUTIONS!

1. Always use the Ball in an open area free of furniture or other items that could get in the way during use.
2. Use the Ball only on smooth surfaces. Do not use ball if deep scratches or gouges exist.
3. Stop and rest if you feel dizzy or short of breath.
4. This product is sold without any warranties or guarantees of any kind and manufacturer and distributor disclaim any liability, loss or damage caused by its use.
5. Intended for sitting, DO NOT stand or kneel on ball.
6. Do not leave child unattended while using the product .
7. Ball is designed to be used by one child at a time.

CARE

1. Clear play area of sharp objects that may puncture ball. Use only on a smooth surface.
2. It is not necessary to deflate ball after use; however, slight leakage may occur over time. Re-inflate when necessary.
3. Hand wash ball with a soft cloth and warm soapy water. Do not use harsh or abrasive chemicals or cleaning tools that may scratch or damage ball.
4. Always check the ball for nicks or scratches before each use. If damaged in any way, do not use.
5. Avoid placing or rolling ball on newspaper, photocopies or other materials printed in ink as ink may permanently mark ball.
6. Avoid exposing ball to rough, sharp or abrasive surfaces, or to heat or excessive sunlight.

CAUTION: DO NOT place Kids Peanut Balance Ball in contact with woodwork, wood furniture or painted walls for any period of time. Damage to finish may occur.