

INSTRUCTIONS

WARNING

1. MAXIMUM LOADING WEIGHT:
15KG.
2. DO NOT STAND OR SIT ON THIS TABLE.
3. CAREFUL NOT TO GET FINGERS CAUGHT
WHEN FOLDING/ UNFOLDING TABLE.
4. DO NOT USE THE TABLE TOP AS A
CHOPPING SURFACE.
5. DO NOT KNOCK OR DRAG THE TABLE.
6. CHECK ALL HINGES ARE IN LOCK POSITION,
THE ALUMINIUM AND THE WINDBOARD ARE
IN PLACE BEFORE USING.
7. DO NOT PLACE HOT ITEMS DIRECTLY ON THE
TOP. ALWAYS USE PLACE MAT.
8. ONLY USE ON EVEN SURFACE.

FAILURE TO FOLLOW THESE WARNINGS
COULD RESULT IN SERIOUS INJURY.

CARE INSTRUCTION


WIPE WITH DAMP CLOTH, DO NOT USE
ABRASIVE MATERIALS OR SOLVENTS.
ENSURE KITCHEN IS CLEAN AND 100%
DRY BEFORE STORING TO PREVENT
MOULD AND MILDEW. STORE IN A DRY
PLACE.

ASSEMBLE THE CAMP KITCHEN



PARTS:

- A: Table frame
- B: Aluminum tube
- C: Aluminum top
- D: Wind board
- E: Carry bag



1. Spread the leg frame out until the sliders reach the stop screw.



2. Assemble top tubes (figure1) then clip them onto the six corners of the leg frame by aligning the holes on the tubes to the pins on the frame (figure2).



3. Attach the table top by inserting the top tube ends into the alu tubes on the bottom sides of the table top.



4. Assemble the wind board D.

YOUR CAMP KITCHEN IS NOW READY TO USE.

Made in China