

USER MANUAL

5 IN 1 BALANCE BIKE

Keycode:43419357



Recommend Age: 12M - 3 years
Max Load: 55.11 lb (25kg)

Please Read this manual carefully before using the product.
In order to avoid dangerous situations, please use this tricycle in
correct way according to this manual.

! WARNING: Only assembly by an adult.

WARNING:

1. The caregiver should not leave when the child is riding.
2. Please check if the parts of the tricycle are well connected before the child uses the tricycle.
3. The tricycle is suitable for children aged 12 months to 3 years.
4. Keep away from fire.
5. In order to avoid suffocation, please keep the plastic cover (tape) away from the baby.
6. Do not place any load on the tricycle, otherwise, it will affect the stability of the tricycle.
7. Make sure all locking devices are locked before using the tricycle.
8. It is forbidden to use the tricycle near stairs, thresholds, and steps. It is forbidden to play near heaters and stoves. It is forbidden to use in downtown areas or roads.
9. The tricycle must be used in a flat, unobstructed location to ensure that it does not tilt during normal use and causes injury.
10. The child does not spend more than one hour each time in a continuous ride, the maximum load of the car is 25kgs, forbid overload, and only for one baby to use alone.
11. The saddle must be locked in place before use, otherwise, it will be dangerous.
12. This product is to be assembled by adults.
13. When the child uses it, always wear a safety certified helmet and knee pads.

Parts List

Please check all parts first



Frame assembled



Pushbar up and down




Handlebar



Foot pedals



Saddle



User Manual

Installation Instructions



1. Press the black circle button to unfold (or fold) the frame



2. Press the buttons at the bottom of frame to unfold (or fold) the rear forks separately



3. Press the buttons as show to rotate wheels outside to unfold (or fold) them



4. Press the black circle button to unfold (or fold) the handlebar bracket



5. Insert the handle bar until the spring bean pops out, and make sure the handle bar can't pull out



6. Insert the saddle until the bottom spring bean pops out, make sure the seat can't pull out, there are two levels to adjust



7. Insert the pushbar down until the black button pops out, make sure the tube can't pull out



8. Insert the pushbar up until the spring bean pops out, make sure the tube can't pull out, there are three levels to adjust



Fig1



Fig2



Fig3

9. Insert and rotate the shaft of the foot pedal until the red button pops out, make sure the pedal can't pull out.
For balance bike configuration, press the red button as Fig2 disassemble foot pedal, insert them under the saddle as Fig3

Five Modes Showing



Push Tricycle Mode (12M+)



Push Balance Bike Mode (18M+)



Tricycle Mode (30M+)



Bike Mode (34M+)



Balance Bike Mode (24-36M+)



Fold Mode

Maintenance:

Please always check and maintain the tricycle, to make your child avoid from accidental injury:

1. Please clean the trike body with a dry cloth. If there is a lot of dirt on it, clean by water and dry it with the cloth.
2. Lubricate the axle and rotating parts regularly, it will expand the products lifespan.
3. Please regularly check and make sure the screws are not loose and components are not damaged. Please replace damaged screws and components.
4. If you need to dismount the trike for transportation or storage, please make reference to manual instruction.
5. Please make sure the trike handle and saddle junction are tightened.