



Lava Lamp Rainbow
43430543 | 69721724
SLR-23010

IMPORTANT SAFETY INSTRUCTIONS:

The following safety precautions should always be followed, to reduce the risk of electric shock, personal injury or fire. It is important to read all of these instructions carefully before using the product, and to save them for future reference or new users.

1. This product must only be used as intended in accordance with the enclosed operating instructions.
2. Do not carry the appliance by the mains cable or pull the cable to remove the plug from the socket.
3. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
4. If the appliance stops unexpectedly or appears to malfunction, switch off the power supply, unplug from the mains and stop using immediately. Seek professional advice to rectify the fault or make repairs.
5. Switch off the power supply and unplug from the mains socket when not in use, before cleaning or changing accessories.
6. Avoid positioning the appliance where the power cable might be accidentally trapped or damaged.
7. Keep the appliance and cable away from sources of heat, sharp objects or anything that may cause damage.
8. Ensure the appliance is switched OFF before connecting the mains power supply.
9. Be aware that some surfaces may become hot. Do not touch hot surfaces and supervise others accordingly.
10. This product has not been designed for use by children.
11. Children should be closely supervised at all times when they are near any electrical appliance.
12. To protect against electric shock, never allow the appliance, the mains cable or plug to come into contact with water or any other liquid.
13. Never reach for any appliance that has fallen into water. Switch off the power supply at the mains immediately and unplug. Do not re-use until the product has been inspected and approved by a qualified electrician.
14. Always ensure that hands are dry before operating or adjusting any switch on the product or touching the plug and mains supply connections.
15. To disconnect, first ensure that all controls are in the OFF position, then remove the plug from the electricity supply.
16. Where relevant keep all ventilation slots, filters, etc. uncovered and clear of debris. Never drop or insert objects into the openings.
17. Do not use outdoors. This appliance has been designed for domestic indoor use only.

ADDITIONAL SAFETY PRECAUTIONS FOR LIGHTING:

1. **DO NOT REMOVE BOTTLE CAP FROM GLASS GLOBE.** Do not remove the cap on the globe or add anything to the globe. The air space at the top of the globe is necessary in order to allow for the expansion of contents. Breaking the seal on the globe shall void the warranty.
2. Remove all excess packaging before assembling.
3. Check and see if the lampholder in the lava lamp base are centered. The socket may have moved during shipping. If this has occurred, then gently use your fingers to re-center it.
4. Only use provided bulb. Variances in bulb size or wattage will produce unsatisfactory operation, fire, or possible breakage of the globe.
5. Run the lamp on a clean and flat surface, away from heated surfaces and direct sunlight. Direct sunlight may cause colors to fade.
6. Allow the lamps to warm up for 1 hour and 45 minutes to 2 hours to ensure it performs at its optimal level. Note: All lava lamp have a coil in the bottom of the globe. This is to accelerate the heating process.
7. Suggest not to continuously operate more than 10 hours.
8. Exercise caution when handling the lamp while it is plugged in. The lamp will take 2 to 3 hours to cool after it has been turned off.
9. To disconnect, turn all controls to the off position, then remove plug from outlet.
10. Do not place the lamp near sources of heat or cold, such as a heater or air conditioner. The lamp operates best at 20-25 ° C room temperature.
11. Handle product with care; the glass globe may break if subjected to any form of sudden impact. If it becomes necessary to clean up broken glass first unplug unit and then use care and safety precautions. (Refer to Clean-Up Instructions below for details.)
12. Do not use any other means to heat up motion lamp besides bulb provided nor attempt to cool it down artificially.
13. Do not shake the lamp while the product is warm. Lamp will become cloudy and unable to repair.
14. Do not operate the lamp on glass surfaces, where aerosol spray is being used, or where oxygen is being administered.
15. If in doubt, consult a qualified electrician.

CLEAN UP INSTRUCTIONS FOR ACCIDENTAL BREAKAGE: If the globe breaks, it is not harmful if it is handled properly. KMART PTY LTD IS NOT RESPONSIBLE FOR DAMAGE CAUSED BY PRODUCT BREAKAGE.:

1. Wear rubber gloves during the clean-up process in order to protect skin irritation and to prevent cuts from broken glass.
2. Carefully pick up and dispose of broken glass and plastic pieces.
3. Use disposable towels to soak up excess liquid (you can use water to aid in clean up because the liquid is water soluble).
4. Thoroughly clean any products soiled by the liquid.
5. After the liquid has been cleaned up, a commercial cleaning detergent may be used to deep clean the area. Prompt clean-up is key.
6. For carpet, blot up spilled material with an absorbent disposable cloth. Follow cleaning directions from your carpet manufacturer.
7. For floors, wipe up with disposable cloth and clean with normal floor cleaning detergent.

BULB REPLACEMENTS INSTRUCTIONS: Before attempting to change the light bulb, please follow the below instructions carefully:

1. Turn off and unplug the lamp from the outlet.
2. Please wait at least one hour, then remove the glass globe from the base. Set aside in a safe location.
3. Please wait at least one hour for the bulb to cool down before replacing. Do not attempt to remove light bulb while hot.
4. Once light bulb is cool to the touch, carefully unscrew from base and discard safely.
5. Replace with the new light bulb by screwing into the base socket. Please see specifications below for correct bulb wattage.
6. Replace glass globe, plug into outlet, and turn your lamp on.




Product specification

- Rated voltage: 220-240V ~ 50Hz
- This lamp requires: 1 x 30W E14 Small Edison Screw incandescent R39 bulb (bulb included)

INSTRUCTIONS FOR INSTALLATION:

1. Caution: Assemble the lamp completely before connecting to the electricity supply.
2. Remove all excess packaging before installation.
3. Install the bulb - 30W R39 E14 Small Edison Screw (provided) into the lampholder.
4. Put the glass bottle on the base as instructions.
5. Cover the metal cap on the bottle.
6. Check to ensure that all the components have been assembled correctly.
7. Connect to the mains supply.

ADDENDEM: WHEN USED FOR THE FIRST TIME, THE COLOUR OF THE WAX MAY BE CLEAR. IT WILL BE TURNED TO A SOLID COLOUR AFTER REPEAT USE.



Troubleshooting		
Problem	Possible reason	Solution
Unit does not work	Connection problem	Check to ensure that all the components have been assembled correctly.
Wax does not melt or could not melt well.	Temperature is low.	Check the bulb wattage is correct or not. This lamp requires 30W R39 incandescent bulb. Other bulbs may produce unsatisfactory operation.
		Ensure the room temperature should be 20-25 °C. Low room temperature may cause the product unsatisfactory operation. Best operation temperature is 21 °C.
		Allow the lamps to warm up for 1 hour and 45 minutes to 2 hours to ensure it performs at its optimal level.
Wax float too much in the water and not come down	Temperature is too high	Check if there is fan or air conditioner working around the product. Air flow may cause the product heat loss too quickly that cause the product not good performance.
		Ensure the room temperature should be 20-25 °C. High room temperature will cause the wax not come down because the wax is too hot. The density of the wax in hot is lower than the water.
Many bubbles in the wax when operation	Wax had been stirred before filled in the bottle. The air entrined in the wax when stirring.	After several times operation, the bubble will be disappeared.
CAUTION: DO NOT SHAKE THE BOTTLE WHILE THE PRODUCT IS WARM. WAX WILL BECOME CLOUDY AND UNABLE TO REPAIR.		

12 Month Warranty

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic, 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us