


135 mm

anko

DESK LAMP WIRELESS CHARGER
User Manual
EWL-23130-A
K: 43-461-691 | T: 70-131-130

1. Device Lay-out



2. Includes

- (1) Desk lamp wireless charger
- (2) USB-C cable
- (3) User manual

3. Technical specifications

Input: 5V = 3A, 9V = 3A

Wireless charging output: 5W/7.5W/10W/15W MAX
(7.5W for iPhone; 10W for Samsung; Some android can up to 15W e.g. Oneplus 10pro.)

PS: For android phones need to have magnetic accessories to attach.

Charging efficiency: ≤75%

Charging distance: ≤6MM

Cool light color temperature: 5800K

Warm light color temperature: 2900K

Cool light/warm light power: 1.6W MAX

4. Indicator light

- (1) **Standby:** Plug in the charging cable, the red light stays on.
- (2) **On Charging:** Blue light stays on.
- (3) **Fully charged:** Red light stays on.
- (4) **Foreign Object Detection:** Blue-red flashes.

5. Operating instruction

- (1) Plug in the charging cable, the wireless charger indicator red light stays on.
- (2) Place your wireless charging enabled device on the charging plate to start charging.
- (3) To ensure efficient charging, a compatible charger is required (sold separately).
- (4) When place the mobile phone, the indicator light change from the red light to blue light; When fully charged, the red light stay on; After you take your mobile phone away from the charging area, the light is red; If there is metal foreign object placed on the charging area, the indicator light of the device will flash Blue-red. At this moment, the wireless charging function stops, and the foreign matter needs to be taken away.
- (5) Touch the "🔌" button to cycle through the LED light modes: ① cool light, ② warm light, ③ cool and warm light, and ④ turn off.

Note: *This product should be used with minimum 15W wall charger.

*To achieve all wireless charger outputs, minimum 27W wall charger should be used.

Front

118 mm

6. Notes

- (1) Do not disassemble or throw into fire or water, to avoid damage.
- (2) Do not use wireless charger in severely hot, humid or corrosive environments, to avoid circuit damage and occurs leakage phenomenon.
- (3) Do not place too close with magnetic stripe or chip card (ID card, credit cards, etc.) to avoid magnetic failure.
- (4) Please keep the distance at least 30cm between implantable medical devices (pacemakers, implantable cochlear, etc.) and the wireless charger, to avoid potential interference with the medical device.
- (5) To take care of the children, to ensure that they won't play the wireless charger as a toy.
- (6) Make sure there is no metal foreign object between the charging pad and phone case when charging.

Some phone cases may affect the charging performance, advise to take it off before charging.

* 12 Month Warranty

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic. 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic. 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us

Back