



Indoor Antenna

Getting Started Guide



1. UNPACK

Unpack the Audiosonic Indoor Antenna from the packaging and check you have all of the components:

1x Audiosonic Indoor Antenna

1x Getting Started Guide



2. CONNECT TO YOUR TV OR SET TOP BOX

Connect the cable attached to your Audiosonic Indoor Antenna to the Antenna IN socket on the back of your TV or Set Top Box.




3. SCAN FOR CHANNELS

Using your TV or Set Top Box remote, access your channel menu and scan for new channels. Consult your TV or Set Top Box manual for details on how to scan for new channels.

4. GETTING THE BEST RECEPTION

There are multiple ways to change the reception you are receiving with your Indoor Antenna. Position the front or back of the Indoor Antenna to face the strongest transmission tower (indicated on <http://myswitch.digitalready.gov.au/> by the green line). Repositioning the dipoles will also affect your reception. It is recommended you try multiple different positions for both the main antenna and the dipoles.



Scan this QR Code with your smartphone or visit <https://myswitch.digitalready.com.au> and enter your address to find out which antenna you need.

12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125** (Australia) or **0800 945 995** (New Zealand) or alternatively, via email at **customer.satisfaction@kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.