

SLACKLINE CLIMBING ROPE INSTRUCTIONS

Keycode: 42961307

WARNING! Requires adult assembly only. Adult supervision required.

Wear personal protective equipment. Always wear a helmet and protective pads.

Not suitable for children younger than 5 years old, contains small parts.

Do not hang the rope around anyone's neck to avoid strangulation hazard.

The product shall not be installed over concrete, asphalt or any other hard surface.

Keep assembly and installation instruction for further reference.


User's maximum weight: 100Kg.

Contents:

The Slackline Climbing Rope consists of 1 piece swing disc, 1 piece buckle set and 1 piece delta clip.

Assembly Instructions:

1. Buckle set and Delta clip installation.



A. Insert a line course into the square buckle set opening on one side, and pull it out on the other side of the opening. Move the buckle set down the line to create space for another buckle set. Repeat this process until all required sets are installed.

B. To open the Delta clip simply twist open the locking portion of the clip. Insert it into the sewn hole of the buckle set and insert the desired obstacle into the delta clip. Twist to close the clip. Note: the shot, flat side of the clip is insert for proper action of clip.

2. Adjust the distance of the square buckle before tightening. Do not move Square Buckle sets when the line is under tension as you may damage your line.

3. Hang climbing rope off the slackline webbing (not included) in the desired location and then your ready to start using the climbing rope.



CARE:

Wipe clean with a damp cloth. Do not use abrasive materials or solvents. Ensure item is clean and 100% dry before storing to prevent mould and mildew. Always store your slackline climbing rope in dark and dry place.

Always inspect all components of your slackline climbing rope prior to use. Do not use this product if you detect any damage to it.

MADE IN CHINA

FOR AU / NZ: IMPORTED FOR KMART

STORES IN AUSTRALIA AND NEW ZEALAND.