

# INSTRUCTIONS

## WARNING

1. MAXIMUM LOADING WEIGHT:  
30KG/66.1LB.
2. DO NOT STAND OR SIT ON THIS TABLE.
3. CAREFUL NOT TO GET FINGERS CAUGHT  
WHEN FOLDING/ UNFOLDING TABLE.
4. DO NOT USE THE TABLE TOP AS A  
CHOPPING SURFACE.
5. DO NOT KNOCK OR DRAG THE TABLE.
6. DO NOT USE THE TABLE UNLESS ALL  
BOLTS, SCREWS AND KNOBS ARE FIRMLY  
SECURED.
7. DO NOT PLACE HOT ITEMS DIRECTLY ON THE  
TOP. ALWAYS USE PLACE MAT.
8. ONLY USE ON THE EVEN SURFACE.

FAILURE TO FOLLOW THESE WARNINGS  
COULD RESULT IN SERIOUS INJURY.

## CARE INSTRUCTION

WIPE WITH DAMP COLTH, DO NOT USE  
ABRASIVE MATERIALS OR SOLVENTS.  
ENSURE KITCHEN IS CLEAN AND 100%  
DRY BEFORE STORING TO PREVENT  
MOULD AND MILDEW. STORE IN A DRY  
PLACE.

## ASSEMBLE THE COMPLETE CAMP KITCHEN




### PARTS:


- A: Table frame
- B: Aluminum top 1
- C: Aluminum top 2
- D: Fabric cabinet
- E: Wind board
- F: Clapboard X 4




1. Unfold the table frame carefully.




2. Unfold the support bar which connected  
the side table, make sure the support bar  
locked. And adjust the feet to height properly.



3. Put the storage D under the side shelf  
and fasten the velcro on the frame.



4. Fix the tray B on the frame, then fix  
the tray C.



5. Assemble the wind board E, and Put  
the 4 clapboard F in the storage area D.

**YOUR CAMP KITCHEN IS NOW  
READY TO USE.**