

**REMINGTON®**  
EST. NEW YORK 1937

# **EFFORTLESS GLIDE SHAVER**

**USE & CARE  
MANUAL**

PLEASE READ  
PRIOR TO USE



To register your product go to  
[www.remington-products.com.au](http://www.remington-products.com.au)  
[www.remington.co.nz](http://www.remington.co.nz)

**2 YEAR WARRANTY**

**WDF4819AU**

## IMPORTANT SAFETY INSTRUCTIONS

**When using appliances, especially when children are present, basic safety precautions should always be followed, including the following:**

- Always store your shaver in a moisture-free area.
- Only use the parts supplied with this appliance.
- Use of non Remington® parts with this product may give rise to a hazardous condition.
- Use this shaver only for its intended use as described in this manual. Do not use attachments not recommended by Remington.
- This appliance should not be used by children or other persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep the appliance away from the edge of table or countertops and out of reach of children and persons with reduced physical, sensory or mental capabilities.
- This appliance is not a toy. Children shall be supervised to ensure they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Ensure that the shaver is switched off when cleaning.
- Keep away from flammable materials.
- To prevent accidents keep the appliance away from hair on your head, your eyelashes as well as clothes, brushes and wire.
- Never drop or insert any object into any opening of this appliance.
- Do not use on people who are asleep.
- Do not use this shaver with a damaged or broken cutting foils or cutters, as injury may occur.
- For household use only.

**SAVE THESE INSTRUCTIONS**

# WDF4819AU EFFORTLESS GLIDE SHAVER

## Use & Care Instruction Manual

Thank you for purchasing your Remington® Effortless Glide Shaver. The model you have chosen can be used in the bath or shower and is designed to provide a gentle, close shave.



### KEY PARTS

- |                        |                        |
|------------------------|------------------------|
| 1. Shaving Head        | 7. Battery Compartment |
| 2. Head Release Button | <b>Also includes:</b>  |
| 3. Dual Flexing Foils  | • Bikini Comb          |
| 4. Flexible Trimmer    | • Storage Pouch        |
| 5. Massaging Strip     | • 2x AAA Batteries     |
| 6. On/Off Switch       | • Cleaning Brush       |

## ABOUT YOUR SHAVER

WDF4819AU SPECIFICATIONS	
Power System	Cordless (battery operated)
Foil Coating	Nickel
Massaging Strip	Yes
Voltage Type	2x AAA batteries (included)
Spare Part	SPW-488AU

### INSERTING BATTERIES

Your shaver requires 2 'AAA' alkaline batteries (first set included). We recommend that you use alkaline batteries for optimal performance.

Make sure the product is turned off.

Rotate the battery compartment cap approximately 1/4 turn counter-clockwise and pull.

Insert 2 "AAA" alkaline batteries, so that the (+) and (-) symbols on the battery align with the corresponding mark in the battery compartment.

Place cap back on unit using the alignment marks and rotate clockwise until the cap snaps into place.

Note: Your shaver will not work if the batteries are inserted incorrectly.

Note: Remove batteries if the unit is not in use for long periods.

### HOW TO USE

Your shaver is suitable for legs, underarms and the bikini area. It can be used dry or in the shower.

#### For Everyday Shaving

1. Remove protective cap.
2. Turn the shaver on.
3. Hold the shaver at a right angle to your skin and move the shaver against the direction of the hair growth.
4. After shaving, turn shaver off.

Note: Before dry shaving, make sure that the area is clean, dry and free from creams or oils.

## **For Longer Hair**

If you have not shaved for a while, use the flexible trimmer before shaving. This will help you achieve a more effective shaving result:

1. Turn shaver on.
2. Hold the shaver with the trimmer facing your leg and slightly tilted towards you (approximately at a 45° angle).
3. Move the trimmer slowly against the direction of the hair growth.
4. After shaving, turn shaver off.

## **Trimming And Shaping**

1. Attach the bikini comb.
2. Turn the shaver on.
3. Hold the shaver at a right angle to your skin and press down gently.
4. Edge and shape the area as desired.
5. After shaving, turn shaver off.

## **FOR BEST SHAVING PERFORMANCE**

We recommend that you use your new shaver daily for two or three weeks to allow time to find the optimum shaving methods for your particular type of hair growth patterns.

### **Caution:**

If your skin is easily irritated by shaving, or you suffer from skin allergies, you should test a section of your arm or leg before using the shaver.

## **CLEANING & MAINTENANCE**

### **Care For Your Shaver**

To ensure long lasting performance of your shaver, clean the head assembly regularly. The easiest and the most hygienic way to clean the shaver is by rinsing the shaving head after use with warm water. Always keep the protective headguard on the shaving head when the shaver is not in use.

### **After Each Use**

1. Ensure the shaver is turned off.
2. Press the release buttons to open the shaver head.
3. Blow on the foils to remove any loose debris.
4. Brush or rinse the accumulated hair from the main body of the shaver, shaving head and cutter assembly.

5. Leave the head assembly open to let the shaver dry completely.
6. Return the shaving head to its original position and snap in place.

Note:

- Ensure that the shaver is turned off when cleaning.
- Do not clean the shaving foils with the brush.
- At regular intervals, put a drop of sewing machine oil onto the foils and cutters heads.
- Rinse only with cool or warm water, not hot water. Do not rinse with water hotter than 70°C.

## REPLACING THE FOILS & CUTTERS

Signs that your foils and cutters need replacing:

**Irritation:** As foils get worn, you may experience skin irritation.

**Pulling:** As the cutters wear, your shave may not feel as close and you may feel the cutters pulling on your hair.

**Wear:** You may notice that the cutters have worn through the foils.

To ensure the continued highest quality performance from your shaver, we recommend that foils and cutters are replaced every 6 months.



### To Replace The Foil

Note: Ensure the shaver is switched off.

1. Remove the shaver head.
2. Gently push the small plastic tabs area at either end of the foil carrier. The foil carrier should then easily detach from the shaving head.
3. To reassemble, snap the new foil carrier into position.
4. Attach the shaving head.

### Caution:

- Only hold the plastic to prevent damage to the foil.
- Do not press on the foil when replacing.





# ACCESSORY ORDER FORM

Article	Part No.	Price each AUD	Price each NZD	Qty	Amount
Replacement Shaving Foil & Cutters for WDF4819AU	SPW-488AU	\$14.99 AUD	\$14.99 NZD		\$
Shaver Saver: Aerosol Spray Cleaner	SP4	\$11.95 AUD	\$14.95 NZD		\$
Face Saver: Pre-shave Powder Stick	SP5	\$11.95 AUD	\$14.95 NZD		\$
<b>IMPORTANT:</b> Pricing in effect at time of publication, inclusive of GST. Subject to change without notice. Postage & handling \$7.50 standard for Australia & New Zealand.				<b>Sub Total</b>	<b>\$</b>
<b>For help or to place an order on the phone call Remington Customer Service:</b>				<b>Postage &amp; handling</b>	<b>\$ 7.50</b>
① Australia: 1800 623 118 (toll free)				<b>TOTAL</b>	<b>\$</b>
② New Zealand: 0800 736 776 (toll free)					

**REMINGTON®**  
EST. NEW YORK 1937

Remington is a Registered Trademark  
of Spectrum Brands, Inc., or one  
of its subsidiaries.



**MAIL YOUR ORDER FORM TO:**

**AUSTRALIAN RESIDENTS:**

Spectrum Brands Australia Pty Ltd  
Locked Bag 3004  
Braeside, VIC 3195  
Australia

**NEW ZEALAND RESIDENTS:**

Spectrum Brands New Zealand Pty Ltd  
PO BOX 9817  
Newmarket, 1149, Auckland  
New Zealand



## MONEY BACK OFFER – AUSTRALIA / NEW ZEALAND ONLY

If within 60 days you are not fully satisfied with your Remington® shaver, just return the shaver with this completed coupon and a copy of your Australian/New Zealand purchase receipt to Remington®. In return, we will send you a cheque for the full purchase price of the shaver. Please allow 6-8 weeks for your cheque to arrive.

Name:

Address:

City:

State:  Postcode:  DOB:  |  |

Contact No: Area Code:  Ph:

Product Model number:

Is this the first Remington shaver you have owned/purchased? Yes  No

Why are you returning this shaver?

Skin Irritation  Shave is not close enough  Takes too long to shave

Other:

**REMINGTON®**  
EST. NEW YORK 1937

**Spectrum Brands Australia Pty Ltd**

Locked Bag 3004  
Braeside, VIC 3195  
AUSTRALIA

Customer service in Australia: 1800 623 118  
E-mail: [consumer.enquiry@remington-products.com.au](mailto:consumer.enquiry@remington-products.com.au)  
Website: [www.remington-products.com.au](http://www.remington-products.com.au)

**Spectrum Brands New Zealand Limited**

PO Box 9817  
Newmarket, Auckland 1149  
NEW ZEALAND

Customer service in New Zealand: 0800 736 776  
E-mail: [info@remington.co.nz](mailto:info@remington.co.nz)  
Website: [www.remington.co.nz](http://www.remington.co.nz)

## To Replace The Cutters:

Note: Ensure the shaver is switched off.

1. Open the shaving head.
2. To remove cutter, grasp cutter between thumb and forefinger and pull upward.
3. To reassemble cutter, place cutter onto oscillator tip. Gently push down clicking into position.



**This product is suitable for use in the bath or shower.**

This product conforms to radio frequency interference requirements.

Any product purchased and used commercially carries a limited 90 Day Warranty.

# Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Limited

## WARRANTY AGAINST DEFECTS

In this warranty:

**Australian Consumer Law** means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

**CGA** means the New Zealand Consumer Guarantees Act 1993;

**Goods** means the product or equipment which was accompanied by this warranty and purchased in Australia or New Zealand, as the case may be;

**Manufacturer, We or us** means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd ACN, 007 070 573; or
2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Limited, as the case may be, contact details as set out at the end of this warranty;

**Supplier** means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

**You** means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for the period of two (2) years from the date of purchase (**Warranty Period**). If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

### Warranty Conditions

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.
5. Consumable parts (such as shaver heads, cutters and foils) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.
6. The warranty granted under clause 3 is limited to repair or replacement only.
7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.

8. In order to claim under the warranty granted under clause 3 you must:
  - (a) Retain this warranty with your receipt/proof of purchase; and
  - (b) Return the Goods to us at the relevant address below or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.
9. This warranty is immediately void if:
  - (a) Any serial number or appliance plate is removed or defaced;
  - (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.
10. The Goods are designed for domestic use only. A limited 90-day Warranty applies to any industrial or commercial use of the Goods. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.
11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.
12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Limited.

Contact us or the Supplier for further details.

#### **Spectrum Brands Australia Pty Ltd**

Locked Bag 3004

Braeside, VIC 3195

AUSTRALIA

Customer service in Australia: 1800 623 118

E-mail: [consumer.enquiry@remington-products.com.au](mailto:consumer.enquiry@remington-products.com.au)

Website: [www.remington-products.com.au](http://www.remington-products.com.au)

#### **Spectrum Brands New Zealand Limited**

PO Box 9817

Newmarket, Auckland 1149

NEW ZEALAND

Customer service in New Zealand: 0800 736 776

E-mail: [info@remington.co.nz](mailto:info@remington.co.nz)

Website: [www.remington.co.nz](http://www.remington.co.nz)

**REMINGTON**<sup>®</sup>  
EST. NEW YORK 1937

#### **REMINGTON SERVICE HOTLINE**

① Australia 1800 623 118 (toll free)

① New Zealand 0800 736 776 (toll free)

#### **AUTHORISED REPAIR CENTRES**

Visit [www.remington-products.com.au](http://www.remington-products.com.au) for Authorised repair centre details.

® Registered Trade Mark of Spectrum Brands Inc., (SBI) or one of its subsidiaries

© 2020 Spectrum Brands Inc.

Rev. 07/20

Part No. T22-0005197-C

Type: WDF4810

