

INSTRUCTIONS

WARNING


1. MAXIMUM LOADING WEIGHT:
30KG.
2. DO NOT STAND OR SIT ON THIS TABLE.
3. CAREFUL NOT TO GET FINGERS CAUGHT
WHEN FOLDING/ UNFOLDING TABLE.
4. DO NOT USE THE TABLE TOP AS A
CHOPPING SURFACE.
5. DO NOT KNOCK OR DRAG THE TABLE.
6. CHECK ALL HINGES ARE IN LOCK POSITION,
THE ALUMINIUM AND THE SHELVES ARE
IN PLACE BEFORE USING.
7. DO NOT PLACE HOT ITEMS DIRECTLY ON THE
TOP. ALWAYS USE PLACE MAT.
8. ONLY USE ON EVEN SURFACE.

FAILURE TO FOLLOW THESE WARNINGS
COULD RESULT IN SERIOUS INJURY.

CARE INSTRUCTION


WIPE WITH DAMP CLOTH, DO NOT USE
ABRASIVE MATERIALS OR SOLVENTS.
ENSURE KITCHEN IS CLEAN AND 100%
DRY BEFORE STORING TO PREVENT
MOULD AND MILDEW. STORE IN A DRY
PLACE.

ASSEMBLE THE CAMP KITCHEN



PARTS:


- A: Table frame
- B: Wind board
- C: MDF top
- D: Clapboard X2
- E: Aluminum top



1. Unfold the table frame carefully.



2. Unfold the support bar which connected the side table, make sure the support bar locked. And adjust the feet to height properly.



3. Fix the tray E on the frame, then fix the tray C.



4. Assemble the wind board B.



5. Put the 2 clapboard D in the storage area.

**YOUR CAMP KITCHEN IS NOW
READY TO USE.**