

# WIGGLE TRIKE INSTRUCTIONS

**Keycode: 43438754**

**WARNING!** Assembly by an adult. Use only under adult supervision.

**WARNING!** Not suitable for children under 3 years old, due to danger of falling.

**WARNING!** Do not use more than one person at a time.

**WARNING!** Protective equipment should be worn.

**WARNING!** Always check that all the parts are tightened and well attached before riding.

**WARNING!** Not suitable for children with a body mass of more than 30kg.

**WARNING!** Do not use on public roads. Do not use it on the ramp or wet surface. Do not use on uneven or unpaved road. Do not use this product at night.

**WARNING!** This product is not designed for off road use and not recommended for stunting.

**WARNING!** This toy has no brake.

Remove the toy and all the parts from the box. Set out all the parts and read the assembly instructions prior to use. Keep the packaging until assembly is complete.

## General instructions

- This toy must be assembled by a responsible adult. Prior to use, make sure that the toy has been assembled properly. Remove all the parts which are not necessary for play before giving the balance bike to your child. Due to the skill it requires, the toy must be used with care in order to avoid falls or collisions likely to injure the user or others.
- To be used with suitable protective equipment, including a helmet, shoes, elbow, wrist and knee protection. Teach the child how to use it safely and responsibly.
- The wobble trike is not a toy for children under the age of 3 years old.

## Directions

- a) This product is not a road vehicle and should be used for leisure purposes only.
- b) For use on smooth, paved surfaces only. Avoid pot holes and bumps which could cause a child to lose control of the balance bike.
- c) Do not allow a child to trike at dusk, at night or at times of limited visibility.
- d) Do not allow a child to trike on roadways, public highways or alleys.
- e) Do not allow a child to trike on steeply sloped areas.
- f) Do not allow a child to trike near steps, swimming pools or other bodies of water.

- g) Do not allow a child to trike without shoes.
- h) Do not allow a child to trike in very loose clothing which could become entangled in the wheels.
- i) Be sure the rider keeps both hands on the handlebar for proper control.
- j) Max user weight 30kg. For use by 1 person at a time. Never ride with more than one person.
- k) If used indoors, ensure the trike is not used nears stoves, heaters, ironing boards or any other hot or dangerous objects.
- l) Avoid bumping into furniture, doors and walls to avoid damage and injury.

## Before and after use


Check the toy before use for loose components and re-tighten where necessary.

Make sure all clamps and locking mechanisms are securely fastened.


Replace worn or broken parts immediately.

Check that wheels are securely attached and that wheels are rolling freely.


## Assembly Instructions:



seat x1




handlebar x1




front wheels x1





clamp x1






frame x1



rear wheels x1

  long screw set x2


  short screw set x4



Step 1: insert frame into front wheels.

Step 2: loosen and insert clamp as image shown.


Step 3: press button and insert handlebar, hearing 'CLICK' and then tighten clamp properly using spanner.



Step 4: insert rear wheels into frame.

**IMPORTANT: PLEASE ADJUST THE REAR WHEELS TO ENSURE ALL 4 WHEELS ARE TOUCHING GROUND AT THE SAME TIME. THEN TIGHTEN SCREWS AS NEXT STEP!**

Step 5: using allen keys to tighten 2x long screw sets.



Scan the code for assembly instructions video.

Step 6: choose the suitable position of seat for your child. Then tighten 4x short screw sets using allen keys.

## Care Instructions

**A. Wheel bearings:** Avoid going through water, oil or sand as this can damage wheel bearings.

To look after the wheel bearings, systematically check that the wheels turn properly by turning the scooter upside-down and using your hand to spin the wheels. If the wheels do not spin they must then be removed to check their condition. First unscrew the wheel axle, remove the axle and detach the wheel, then carefully push the two wheel bearings out of their housing. If they are chipped or dented, new ones should be bought. If there is no visible damage, they must then be oiled. To do this, remove all traces of grease, mud or dust with a kitchen towel or cloth, and re-oil them with a grease spray or by leaving them to soak overnight in oil [turn them several times in the oil first]. Remove reassemble the wheel bearings and axles, followed by the wheel, onto the scooter. proceed in the same manner for the other wheel.

**B. Wheels:** The wheels wear down with time and can be pierced if overly used on rough surfaces. The back wheel on which the brake is applied is particularly affected after several hours of braking. In the interests of safety, they should be checked regularly and changed if necessary.

**C. Modifications:** The original product must by no means be modified except for the maintenance-related changes mentioned in these instructions.

**D. Nuts and axles:** These should also be checked regularly. They can become loose after a while in which case they should be tightened. They can become worn and not tightened properly, in which case they should be replaced.

**MADE IN CHINA**

### **CUSTOMER SERVICE**

**KMART AU:** 1800 124 125

**KMART NZ:** 0800 945 995

**TARGET AU:** 1300 753 567