



# Wooden plyo box

Keycode:43488865


## Parts List



1. Top/Bottom Panel  
x 2pcs




2. Side Panel  
x 2pcs



3. Front/Back Panel  
x 2pcs



4. Medium reinforcement piece  
x 1pc



5. Shortest reinforcement piece  
x 1pc




6. Longest reinforcement piece  
x 1pc



7. Self-tapping screw  
x 38pcs  
(1pc spare part included)


## Assembly Instruction

Step 1: Assemble the main frame except the top panel: please refer to below image (Fig. 1) to assemble each panel in their position, secure them with 24pcs self-tapping screw(Part 7) by screwdriver(not included).




( Fig 1 )

Step 2: Assemble the reinforcement pieces: please refer to below image (Fig. 2) to assemble each reinforcement piece in their position, secure them with 1pc self-tapping screw(Part 7) by screwdriver(not included).




( Fig 2 )

Step 3: Put the reinforcement pieces into main frame: please refer to below image (Fig. 3) to insert the reinforcement piece.




( Fig 3 )

Step 4: Assemble the top panel: please refer to below image (Fig. 4) to assemble the top panel in its position, secure it with 12pcs self-tapping screw(Part 7) by screwdriver(not included).



( Fig 4 )

Step 5: Assembly is completed.



( Fig 5 )

## Warning

1. CHOKING HAZARD, small part. Not for children under 3 years.
2. Requires adult assembly only. Use only under adult supervision.
3. The maximum load capacity for the user is 120Kg.
4. Screws will get loose after exercise, so please check and tighten the screws properly every week so as to avoid any possible damage to the equipment or personal injury.
5. Always store the equipment on a flat surface and in a dry and well ventilated area.