



K: 43-398-171 | T: 69-316-449

Model: JY-M503


**Wired Headphone**

Instruction manual



Thank you for choosing our Anko headphone.  
We hope you enjoy using it.

This headphone has an inline microphone and music control function along with a call answering function that work on most IOS and Android devices. Please connect the headphone cable with standard 3.5mm plug to your devices before using.



- Overview:**
1. Volume up
  2. Call answer and music control button
  3. Volume down
  4. Microphone

**Operation**

To	Press
Volume up	Press <b>+</b> repeatedly as desired
Volume down	Press <b>-</b> repeatedly as desired
<b>Call Functions</b>	
Answer a call	Press <b>☎</b> once
End a call	Long press <b>☎</b> 2 seconds
Reject a call	Long press <b>☎</b> 2 seconds
<b>Music Control Functions</b>	
Pause music	Press <b>⏸</b> once
Play music	Press <b>⏪</b> once
To the next track	Press <b>⏩</b> twice
To the previous track	Press <b>⏮</b> 3 times

**Warning:** High volume can cause hearing loss. Please enjoy music at a moderate volume to prevent adverse effects on the hearing.

**12 Month Warranty**

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at <a href="http://kmart.com.au">kmart.com.au</a>	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic, 3027 Customer Service: 1300 753 567 or via Customer Help at <a href="http://target.com.au/help/contact-us">target.com.au/help/contact-us</a>