

anko

Wireless Charging Stereo Headphones



Keycode:42895848

INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY

AND RETAIN FOR FUTURE USE

Getting started

- Remove the product from the box.
- Please retain all packaging after you have checked and counted all the parts and the contents against the Package Contents list.

Package Contents

- Wireless Charging (Qi) Standard Wireless Charge Bluetooth Stereo Headphones
- USB charging cable
- Auxiliary audio cable
- Wireless Charging Pad
- Instruction Manual

Key Features

- Wireless Charging (Qi) Enabled Bluetooth Stereo Headphone
- Superior sound with passive noise cancellation & enhanced bass
- Connect and stream wireless music anytime, anywhere
- Built-in mic, never miss your phone calls - answer hands-free
- Your music & calls at finger-tips
- Built-in rechargeable battery
- Easier recharging - no need for wires while recharging the headphone. Just place it on the wireless charging pad
- Wireless Charging Pad included

Safety Instructions

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not use the unit with wet hands.

Do not put objects into any of the openings.

Keep the unit free from dust, lint etc.


Do not use this unit for anything other than its intended use.

Keep the unit out of reach of children.

This product is not a toy.

Do not use the handset at excessive volume levels, as damage to hearing may occur.

Description of Parts:



1	Charging port
2	ON/OFF Button
3	Play / Pause / Phone Button
4	Volume Decrease (-) / Previous Track
5	Mode/Voice Assistant Button
6	Built-In Microphone
7	Volume Increase (+) / Next Track
8	LED Light Indicator
9	Micro SD (TF) Card Slot
10	Aux-in Port
11	Wireless Charging Receiver
12	Wireless Charging Pad

INSTRUCTIONS FOR USE

Charging Instructions

The Bluetooth Headphone has built-in rechargeable battery and wireless charging receiver. When the battery is drained out, it would turn OFF automatically. Please recharge the battery by following either method every time it drains out.

Method 1: Plug the Micro USB end of the included USB rechargeable cable into the charging port. Plug the other end into a USB port on your computer or other devices made for USB charging. Red LED Light illuminates indicating that the Headphone is being charged.

It takes 2-3 hours to fully charge the Headphone. Once the Headphone is fully charged, LED Light would turn off.

Method 2: Fold the Headphone to a state with its Wireless charger receiver at the bottom position and the LED light indicator on vertical position for viewing easily (as the diagram shown). Connect the Wireless charging pad (included) with the USB cable (included) to a power outlet rated DC 5V 2A, red LED indicator light around the Wireless charging pad turns on, then, put the Headphone with its Wireless charging receiver on the middle position of the Wireless charging pad. Red LED Light on the Headphone illuminates, and the red LED indicator light around the Wireless charging pad will turn to auto-change of blue LED light, indicating that the Headphone is being charged.

It takes 2-3 hours to fully charge the Headphone. Once the Headphone is fully charged, red LED Light on it would turn off.

Switching on/off the device

Press and hold the ON/OFF button for 4 seconds to turn on the device, or 3 seconds to turn off.

Pairing the device with Bluetooth devices (phone or music device)

Ensure the device is turned off, then press and hold the ON/OFF button for 4 seconds to turn on the device, and the LED flashes red and blue. After few seconds, you would hear an indication tone. Place the Bluetooth Headphone and Bluetooth device (phone or music device) so that they are no further than 3 feet apart;

Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.

Once you have activated Bluetooth on your device, select the "Anko headphone" from the list of available Bluetooth devices.

If required, enter the password '0000' to confirm & finalize pairing.

Once paired successfully, you would hear another indication tone, and the LED flashes blue slowly.

You can now start to use the device.

If pairing is unsuccessful, turn the device OFF and then re-pair following the above steps.

The Bluetooth Headphone will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the steps outlined above.

Once the Bluetooth Headphone is paired with your device the music will transmit through the Bluetooth headphone. Please refer to your device's user manual for further information.

Function Summary

Listening to Music

Once the Headphone is paired with your device you can stream music wirelessly through the Bluetooth Headphone. Should you encounter any problems while streaming please refer your device's user manual for further information.

Control Function

Function	Operation	Button
Increase Volume	Playing music	Press and hold the + button will increase the volume
Decrease Volume	Playing music	Press and hold the - button will decrease the volume
Pause	Playing music	Short press on the Play / Pause button will pause the music
Play	Pausing	Short press on the Play / Pause button will restart the music
Previous track	Playing music	A short press each time on the Previous track button will return you to the previous track
Next track	Playing music	A short press each time on the Next track button will take you to the next track

An indication tone will alert you when the volume is adjusted to minimum or maximum level.

Making a call with the Bluetooth Headphone in Bluetooth mode

Basic operation

Function	Operation	Button
Answer a call	Incoming Call	Press the Phone button once to answer an incoming call
Reject a call	Incoming Call	Press and hold the Phone button for 2 seconds
End a call	Incoming Call	After your phone conversation, short press the Phone button.
Increase Volume	During a call	Press and hold the + button will increase the volume
Decrease Volume	During a call	Press and hold the - button will decrease the volume
Redial last number	Standby mode and connected to a device	Short press the Phone button twice

Please Note

- Not all mobile phones support all the functions listed above. Please refer to your cell phone's user's manual for further information.
- Certain functions and indication tone maybe vary depending on your mobile phone.

Voice Assistant Operation

Voice Assistant is a built-in interactive feature that allows you to Start Conversation with Your Siri or Google Assistant, with a click of a button on your device.

This feature enables you to ask questions and seek assistance on a number of things from your Voice Assistant, even when you're several feet away from your phone. Below are some of the many examples listed below.

Note: Google Assistant is available on eligible Android 5.0 devices or later. Works on Lollipop, Marshmallow and Nougat Android Phones with Google Play Services, >1.5GB of memory and 720P or higher screen resolution. Please

ensure Google Assistant App is downloaded and made as default Voice Assistant on your mobile device.

While the headphone is paired using Bluetooth, short press the Voice Assistant button once to start conversation with your Siri or Google Assistant. An indication tone would be heard before you speak into the headphone.

- Example 1: Short press the Voice Assistant button once and then speak into the headphones, how's the weather today?
Voice Assistant will reply with something like: mainly cloudy with a few showers.
- Example 2: Short press the Voice Assistant button once, and then speak into the headphones, what's the time now?
Voice Assistant will reply with something like: it is 8pm now.
- More examples:
Set an alarm for 7am tomorrow.
Play some music.
What's in the news?

Listening to Music using Micro SD (TF) card slot

1. Turn on the Headphone.
2. Insert Micro SD (TF) card preloaded with songs into the Micro SD (TF) card slot, music would be automatically streamed.
3. To Skip Next Track – Short press the Next Track button.
4. To Skip Previous Track – Short press the Previous Track button.
5. Press Play / Pause button to Play or Pause a track.
6. Long press the + or - button to increase or decrease the volume.

Note: While using Bluetooth, if you insert Micro SD (TF) card, Headphone would disconnect the Bluetooth connection and switch to Micro SD (TF) card function. You can short press the Mode button twice again, to select the Bluetooth mode.

Listening to Music using AUX-In Mode

Insert the 3.5mm auxiliary cable (provided) to the Aux input of the Headphone. And, the other end of the cable connects to the audio device (such as computer / tablet etc.).

Select your favorite song at the source device and play.

(Note: Using this Aux-in mode, you do not need to turn on the Headphone, and you need to control the volume increase/decrease, play/pause, next/previous track through your source device only.)

LED indicator

Please refer to the below tables for a list of the LED statuses whilst using the Bluetooth headphone.

Charging Indication

LED indicator	Status of the BT Headphone
Red LED	Charging
Red LED off	Charging Completed

LED Indication

LED indicator	Status of the BT Headphone
LED flashes red and blue	Pairing mode

Troubleshooting

Symptom	Solution
No Sound	<ul style="list-style-type: none">• Power On the headphones and charge the battery• Increase the volume on your headphones, your mobile device and music source• Move your mobile device closer to the headphones and away from any interference or obstructions• User a different music source• Connect another mobile device
Poor Sound Quality	<ul style="list-style-type: none">• User a different music source

	<ul style="list-style-type: none"> • Connect another mobile device • Move your mobile device closer to the headphones and away from any interference or obstructions
Battery Won't Charge	<ul style="list-style-type: none"> • Secure the ends of the USB charging cable • Try another charging source
Your Google Assistant not responding	<ul style="list-style-type: none"> • This is only available for Android Mobile Devices • Make sure Google Assistant is downloaded on your mobile device and set to default voice assistant • Make sure your Android Mobile Device is Bluetooth paired with Headphone • Make sure you are in a country where Google Assistant is available • For additional support, visit www.support.google.com/assistant
Loud Dial Tone Noise When Activating Google Assistant	<ul style="list-style-type: none"> • Make sure you have latest version of Google Assistant App • On your Android mobile device, go to Settings > Apps > Google App > Disable. After that, tap Enable (If you have uninstalled Google App, please uninstall and reinstall the App).

Care and Maintenance

Read the following recommendations before using the Bluetooth Headphone. Following these you will be able to enjoy the product for many years.

- Don't expose the Bluetooth Headphone to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the device.
- Don't expose the device to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the device in a fire as it will result in an explosion.
- Don't expose the device to contact with sharp objects as this will cause scratches and damage.

- Don't let the device fall on the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the device as it may get damaged if you are not professional.

Specifications

Bluetooth specification	Bluetooth 5.0
Operating distance	10M
Working time	up to 10 hours (moderate volume)
Charging input voltage	DC 5V
Charging time	2-3 hours
Speaker Power	2 x 10mW
Built-In Battery	400mAh

(Note: Battery life & charging time may vary based on usage & types of devices used.)