

anko

Instruction manual




Keycode: 42967347
Bluetooth® Active Noise Cancelling Headphone

Please read all the information carefully before you use the product and keep the manual for future reference.

PRODUCT SPECIFICATIONS:

- Charge Input voltage: DC5V,1A
- Signal ration:90db
- Frequency range:20Hz-20Khz
- Charging time:2-3hours
- Play time(headphone mode): 8-10 hours,
- Bluetooth version: 5.0
- Microphone sensitivity: -32db
- Working range: 10 meters

PRODUCT OVERVIEW



: Long press to power on or off



: Short press to reduce volume; Long press to previous song



: Play music or Pause music




: When a call coming, short press to answer the call, Long press to refuse the call; double press to redial the last call that you have.




: Short press to increase volume, Long press to next song

Active Noise Cancelling:

to activate the ANC function, switch this button , and the indicator light is on in blue and it could reduce the low frequency background noise by $22\text{dB} \pm 3\text{dB}$.



BLUETOOTH PAIRING OPERATION METHOD

Long press  to power on and enter Bluetooth pairing model. At this time search the corresponding Bluetooth device name "KM42967347" on the phone, click it on the mobile phone for the Bluetooth pairing.

CHARGE THE HEADSET

The internal rechargeable battery inside must be fully charged before you start to use the headset.

Connect one end of the USB cable to the charger or the USB interface of the computer, and the other end to the charge interface of the headset.

Red light on: charging.

Red light off: charged fully.

NOTE

- Keep the product dry. Do not store it in damp areas.
- Do not exposure the product to the sun or high temperature.
- Do not attempt to open the product, especially operated by non-professional person.
- Do not make the product fall down, shake the product violently, or strike the product with hard objects.
- Do not use something sharp to scratch the surface of the product.
- Do not continuously charge the headset for over 10 hours to avoid affecting the service life.

WARNING

- Working temperature: 0°C~ 45°C.
- Battery cannot be subjected to high or low extreme temperatures, low air pressure at high altitude during use, storage or transportation.
- Replacement of a battery with an incorrect type that can result in an explosion or the leakage of flammable liquid or gas.
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving the battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.