

2PK SWING ROPES INSTRUCTIONS

Keycode: 42980353

WARNING! Requires adult assembly only. Adult supervision required.

Wear personal protective equipment. Always wear a helmet and protective pads.

Not suitable for children younger than 5 years old, contains small parts.

Do not hang the string around anyone's neck to avoid strangulation hazard.

The product shall not be installed over concrete, asphalt or any other hard surface.

Keep assembly and installation instruction for further reference.

User's maximum weight: 100Kg.

Contents:

The 2PK Swing Ropes consists of 2 pieces swing rope, 2 pieces buckle set and 2 pieces delta clip.

Assembly Instructions:

1. Buckle set and Delta clip installation.



A. Insert a line course into the square buckle set opening on one side, and pull it out on the other side of the opening. Move the buckle set down the line to create space for another buckle set. Repeat this process until all required sets are installed.

B. To open the Delta clip simply twist open the locking portion of the clip. Insert it into the sewn hole of the buckle set and insert the desired obstacle into the delta clip. Twist to close the clip. Note: the short, flat side of the clip should be inserted for proper action of clip.



2. Adjust the distance of the square buckle before tightening. Do not move Square Buckle sets when the line is under tension as you may damage your line.

3. Hang swing ropes on the tightened webbing slackline(not included) at the desired point and then you're ready to commence use.

CARE:

Wipe clean with a dry cloth. Do not use abrasive materials or solvents. Ensure item is clean and 100% dry before storing to prevent mould and mildew. Always store your swing rope in dark and dry place.

Always inspect all components of your swing rope prior to use. Do not use this product if you detect any damage to it.

MADE IN CHINA

FOR AU / NZ: IMPORTED FOR KMART

STORES IN AUSTRALIA AND NEW ZEALAND.