

# Assembly Instructions

## 43000579 Kitchen Bench Prep Trolley

### CARE INSTRUCTIONS:










WIPE CLEAN WITH SOFT DAMP CLOTH. DO NOT USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. CHECK AND TIGHTEN ALL PARTS REGULARLY. STORE IN A DRY PLACE AND KEEP AWAY FROM DIRECT WATER AND SUNLIGHT. FOR INDOOR AND DOMESTIC USE ONLY.








### WARNING:













DO NOT STAND, SIT OR LEAN ON THE TROLLEY. USE ONLY ON A FLAT SURFACE. WHEN USE THE TOP AS A CHOPPING SURFACE, LOCK ALL WHEELS AND PLACE THE TROLLEY AGAINST WALL OR OTHER FIXED UNIT TO AVOID UNINTENDED MOVING. DO NOT USE UNTIL ALL SCREWS, BOLTS AND KNOBS ARE FIRMLY SECURED. THIS PRODUCT CONTAINS SMALL PARTS AND SHARP POINTS, KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.


**MAXIMUM SAFE LOAD:** 10KG FOR TOP PANEL, 2KG FOR DRAWER, 3KG FOR WINESHELF, 3KG FOR WIRE BASKET, 3KG FOR BOTTOM SHELF.

### Hardware list

	A	6*30mm	6PCS
	B	15*9mm	6PCS
	C	6*30mm	10PCS
	D	4*35mm	4PCS
	E	Handle	1PC
	F	4*16mm	1PC
	G	6*40mm	8PCS
	H	10*10mm	8PCS
	I	Allen Key	1PC


	J	Drawer Stopper	2PCS
	K	Metal Pin	2PCS
	L	6*27mm	4PCS
	M	Nut	4PCS
	N	Wrench	1PC
	O	Wheel without stopper	2PCS
	P	Wheel with stopper	2PCS

	①	1PC		②	1PC		③	1PC
	④	1PC		⑤	1PC		⑥	1PC
	⑦	2PCS		⑧	1PC		⑨	1PC
	⑩	1PC		⑪	1PC		⑫	1PC




Do not tighten the screws fully during assembly.  
Fully tighten screws after the final assembly steps.

### STEP1




Put H onto board 4&7 into the corresponding position (as per diagram). Put part C on to frame 3 into the corresponding position as per diagram. Attach frame board 4&7 onto frame 3 with screw G. Tighten with Alley key I.

### STEP2




Attach board 6 on to board 7 from step 1.

### STEP3





Put H onto board 4&7 into the corresponding position (as per diagram). Put part C on to frame 2 into the corresponding position as per diagram. Attach frame 2 into board 4&7&6 from step 2 with screw G.

### STEP4





Attach part O & P onto the legs with screw M&L. Tighten with Alley key I. Kindly reminder: Part O is the wheel without stopper. Part P is the wheel with stopper. Note: use part N onto the nut M to align the part L, tighten with Alley key I.

## STEP5




Attach A onto board 1.

## STEP6




Attach board 1 from step 5 onto frame 2&3 from step 4 with screw B & C. Ensure all parts align.

## STEP7




Attach board 8 & 10 onto board 9 with part D. Put board 11 onto board 8 & 10. Fix part A onto board 11, and fix part E onto Board 11 with screw F. Attach board 12 to board 8 & 10 with part B&C.

## STEP8




Put drawer from step 7 onto trolley from step 5, when drawer is put into 1/3, then fix J into the corresponding position as per diagram.

## STEP9



Put part 5 onto trolley from step 8, then fix K into the corresponding position as per diagram.

## STEP10



Finish the assembly.