

10.5cm

10.5cm

43024087 6 CUP ESPRESSO MAKER

EN English

NOTE! Please read all the instructions carefully before brewing. Failure to comply with the safeguards and warnings may result in burns and other serious injuries.

SAFETY INSTRUCTIONS

- 1. Take special care when the coffee maker is hot.
2. Do not leave the coffee maker on the heat source unsupervised.
3. Do not use the coffee maker without water.
4. Do not wash the coffee maker in dishwasher.
5. Do not use to prepare cocoa, tea, instant coffee, herbs.
6. Do not immerse hot coffee maker in cold water.
7. Once the brewing process is completed, take the coffee maker off the heat source immediately.
8. Before cleaning, wait until the coffee maker cools down.
9. Wash in hot water with a soft sponge and delicate detergent.
10. After washing, dry the coffee maker. Do not screw the parts of the coffee maker if wet.
11. Before each use check the condition of particular elements including the safety valve, that should remain stationary.
12. Do not use the coffee maker if damaged.
13. Pay special attention to the sieves-do not use the coffee maker if the sieves are clogged.
14. The machine must not be used by children.
15. Store the coffee maker out of each of children.

INTENDED PURPOSE

The machine is intended for household use on gas, ceramic, induction and electric stovetops.

BEFORE FIRST USE

Before first use make sure the coffee maker is complete. Clean the coffee maker carefully. NOTE! Remove the gasket with the sieve (2) from the coffee maker in order to clean it.

MACHINE COMPONENTS

- 1. Upper chamber
2. Gasket with a sieve
3. Coffee container with a sieve
4. Safety valve
5. Lower chamber




Diagram 1

COFFEE BREWING

Before making a coffee, check the condition of the safety valve.

- 1. Pour water to the lower chamber (5) to the level of the safety valve (diagram 2) - about 280 ml. To avoid mineral buildup use filtered or boiled water.

NOTE! Do not immerse the safety valve in water.

- 2. Put the coffee container (3) in the lower chamber.

NOTE! Check if the sieve is not clogged.

- 3. Put coffee into the container (3).

Indications: Do not use very finely ground coffee to avoid clogging of the sieve.

NOTE! DO NOT TAMP THE COFFEE. If you tamp the coffee, the sieve may get clogged and the coffee maker may start leaking during the brewing process through the threaded connection of the upper and the lower chamber.

- 4. Remove any excess coffee from the edges of the container.
5. Screw the upper chamber onto the lower chamber securely. Before screwing the upper chamber, make sure that the seal with the sieve (2) are not clogged. Do not force by holding the handle.
6. Put the coffee maker on the hob so that the diameter of the heat source is adequate to the size of the lower chamber. If you are using a gas stove, make sure the heat source does not extend beyond the edges of the coffee maker.
7. Remove the coffee maker from the hob immediately once the upper chamber is filled with coffee. Do not wait until the coffee stops percolating to the upper chamber. If you let the water sit in the lower chamber you will prevent it from overheating and darkening.
8. Once you have finished, wait until the coffee maker cools down. Wash and dry. Keep away from children. Use only original spare elements. The manufacturer shall not be held liable for defects resulting from improper use of the coffee maker. The warranty does not cover any mechanical damage.




Diagram 2

14.8cm