

MANUFACTURER:

Robotime C&C (Jiangsu) Co., Ltd.

ADDRESS:

No. 18 Changxing Road, Shuyang, Suqian City, Jiangsu Province, China

Designed by **ROBOTIME**
www.robotime.com
MADE IN CHINA

49.1DGM07.342.B

Rolife

Wonderful Life

Jimmy's Studio

- DGM07 -



Pictures for reference only, subject to our existing products.

Please read this manual before assembling.

Brief Introduction

Tips of glue (The picture is only for reference.)

1. Liquid glue is used to glue large wood parts and other materials.
2. Do not use too much glue in case of longer time to dry. It may also affect the appearance of completed products.




Tips of assembling

1. Small parts are included. Children must assemble under the guidance of adults in case of swallowing by mistake.
2. Put the remains back to original bags after taking enough dosage in each step till completed. (In case of missing materials)
3. All the dimension in the instruction is shown in millimeter (mm).
4. Find the part you need according to material list and the 1:1 part illustration paper (for wood parts). Check its number and size carefully before assembling. See Part Number Explanation at the end of this page.


Tools included



Tools not included



Remove the part properly



Remove the wood part with knife. Polish with sandpaper for preparation. (It's easier to remove parts by cutting the edge front and back.)


Find wood parts based on the part illustration paper

- 1 Find part number paper in the box.
- 2 Put the part in parts number paper to know parts number.

Part number explanation


1-619: Parts in bag No.1, the number of the part is 619. (Only note the part number in the steps.)

Sequence of Assembly



Small Components

A




B



C




D




21


Workbench



1




2



3




4



5




6




7



8



9




10



11



12



13



02

14

A
B

15

Champagne metal wire
15
x3 pcs

16

9
dx3 pcs
I1
I1
Side view

17

Drawer A
Golden plate
Drawer B
Golden bead

Glue as shown.

18

Mix brown pigment and water in a ratio of 1:3. Paint and glue as shown.

19

Drawer A
Drawer B
Golden plate
Golden bead

Glue as shown. Completed.

Side cabinet

1-A5
1-A6
1-B50
1-B51
1-B53
1-B57
1-B59
1-B63
1-B77
1-B78

Material List
1 Wood pieces 13pcs
2 Champagne metal wire L30mm 1pc (Bag No.2)

1

A8
A5

Overlap and glue as shown.

2

Complete 2 pieces in total.

3

B83
B51

Glue as shown.

4

B59
B77

Glue as shown.

5

B53

Glue as shown.

6

B57

Glue as shown.

7

B50

Glue B50. Mix brown pigment and water in a ratio of 1:3, then paint.

3

Completed as shown.

Framework

1-B81
1-B82
1-B83
1-B84
1-B85
1-B86
1-D1
1-D2
1-D3
K1
K10
K13

Material List
1 Wood pieces 10pcs
2 Transparent sheet 1pc
3 Paper-cut K1, K10, K13

1

D2

Paint the side of D2 white. (Paint the side of D1, D3 white.)

2

B85
B81
B82
B83
B84

Glue as shown.

3

Paint it white and dry for preparation.

4

B86

Paint B86 green and dry for preparation.

5

Transparent sheet

Glue the sheet and trim. (Remove the protective film on the sheet.)

6

D1

Glue as shown.

7

D3
K10

Glue as shown.

8

D2
K1

Glue as shown.

9

Glue as shown.

10

Glue as shown.

11

Frame A
Frame B
K13

Glue as shown.

Plant 2

Material List

- 1 Orange paper 1pc (Bag No.1)
- 2 Green paper 1pc (Bag No.1)
- 3 Yellow paper 1pc (Bag No.1)
- 4 Coppery flowerpot 1pc (Bag No.3)
- 5 Yellow stamen 4pcs (Bag No.3)

1

Cut 8 squares 15x15mm as shown, 2 in yellow and 6 in orange.

2

Fold squares as shown based on the dotted line.

3

Glue as shown.

4

Complete 8 flowers.

5

Cut the 30x30mm green paper as shown.

6

Wrap and glue.

7

Cut the excessive and glue as shown.

Coppery flowerpot

Plant 3

Material List

- 1 Dry plant are not included
- 2 Blue flower 4pcs (Bag No.3)
- 3 Burlywood bead 1pc (Bag No.3)

1

Glue as shown.

Dry plant

Burlywood bead

2

Glue as shown.

Blue flower

Decorative rack

Material List

- 1 Wood pieces 2pcs
- 2 Silver steel wire L200mm 1pc (Bag No.2)

1

Cut and wind as shown. Measure the length needed in gluing it onto the wall.

2

Wind as shown.

8

Cut as shown.

Champagne metal wire

15

x2pcs

9

Bend as shown and flatten both ends.

2

9

a x2pcs

1

1

Side view

10

Glue as shown.

Wooden book

Material List

- 1 Wood pieces 2pcs
- 2 Silver steel wire L130mm 1pc (Bag No.2)

1

Overlap and glue as shown.

A12 x2

2

Cut as shown.

Silver steel wire

130

3

Twine as shown to fix.

4

Mix brown pigment and water in a ratio of 1:3, then paint.

Tabletop cabinet

Material List

- 1 Wood pieces 6pcs
- 2 Brown metal wire L48mm 1pc (Bag No.2)

1

Glue as shown.

B26

B26

B30

B30

2

Glue as shown.

B35

3

Mix brown pigment and water in a ratio of 1:3, then paint.

4

Cut the brown metal wire. Flatten both ends and bend as shown.

12

x4pcs

x4pcs

6

a x4pcs

2

1

1

2

Front view

Side view

5

Glue as shown.

a

Storage box

Material List


- 1 Paper-cut K31-K40, K42-K47
- 2 Golden paper 30×4mm 1pc (Bag No.1)




1 Fold as shown and glue.



2 Fold as shown and glue.




3 Cut as shown.



4 Fold as shown and glue.



5 Roll K43 as shown and glue K42 onto both ends. Complete another two pieces in the same way.




6 Fold as shown and glue.

Storage cabinet

Material List

- 1 Wood pieces 26pcs
- 2 Champagne metal wire L60mm 1pc (Bag No.2)
- 3 Golden bead 2pcs (Bag No.3)
- 4 Golden paper 1pc (Bag No.1)
- 5 Transparent sheet 1pc
- 6 Paper-cut K41



1 Glue as shown.




2 Glue as shown.


Plant 1

Material List


- 1 Brown clay some (Bag No.2)
- 2 Green paper 1pc (Bag No.1)
- 3 Stem L260mm 1pc (Bag No.2)
- 4 Paper-cut K16-K18




1 Cut the stem as shown.




2 Twine "A", "B", "C" together as shown.




3 Twine "A" and "D" as shown.




4 The branches are completed.



5 Cut the green paper as shown.




6 Fold in half. Then glue the same three pieces together by gluing them in pairs, and glue one branch in the center.



7 Glue as shown.



8 Trim as shown.



9 Bend as shown.




10 Fold and glue as shown.





11 Glue as shown.





12 Put some clay into the pot and insert the plant in it.

10  K11
Fold in half.

11  K12
Fold in half.

12  b c
Glue as shown.

13  c x2pcs b
Glue as shown.

14  Decoration A a
Glue as shown.


15  Decoration B a
Glue as shown.


Calendar


  K2  K15


Material List
 1 Aluminum sheet 1pc (Bag No.2)
 2 Paper-cut K2, K15


1  K2
Glue as shown.


2  K15
Glue as shown.


3  K15
Fold and glue.


4  12 5 8
Cut the aluminum sheet and bend as shown.


5  K15
Glue as shown and poke on the center.


6  K15
Glue as shown. Completed.


3  B71 B72 B73
Glue as shown.

4  b B8
Glue as shown.


5  B5 C1
Glue as shown.

6  c C1
Glue as shown.

7  a b
Glue as shown.

8  c
Glue as shown.

9  B7
Glue as shown.


10  B7
Glue as shown.


11  B6
Glue B6 near the front.


12  A7 B2
Glue A7 onto the mark line of B2, and paint it green.


13  A6 B1
Glue as shown and paint.


14  Transparent sheet
Tear off the films of transparent sheet on both sides.


15  Transparent sheet
Stick transparent sheet on backside.


16  d e f
Cut as shown.

17  Paint as shown.


18  A9 B9
Glue as shown.

19  B9
Glue as shown.


20  Glue as shown and paint.




Cut as shown.




Cut as shown and fold centrally.



Cut as shown.



Cut as shown.




Cut as shown.



Glue as shown.




Glue as shown.



Glue as shown.



Put them here without glue.




Fix them without glue.



Cut as shown.



Glue as shown.




Cut as shown.




Clamp two ends flat with plier.




Bend as shown.




Glue as shown.



Cut as shown.



Cut as shown.



Bend as shown.




Glue as shown.


Decoration

Material List


- ① Aluminum sheet 1pc (Bag No.2)
- ② Silver steel wire L60mm 1pc (Bag No.2)
- ③ Paper-cut K11, K12



Cut as shown.




Bend as shown.



Cut the aluminum sheet as shown.




Bend as shown.



Fold as shown.




Fold as shown.



Cut as shown.



Bend as shown.



Bend as shown.

Candlestick



Material List

- 1 Paper stick L8mm 1pc (Bag No.2)
- 2 Big coppery bead 1pc (Bag No.3)
- 3 Golden button 1pc (Bag No.3)
- 4 Golden flower 1pc (Bag No.3)
- 5 Champagne metal wire L10mm 1pc (Bag No.2)




1



Cut the stick spirally as shown. Peel off the paper till you see 1mm of its axis.

2



As shown.


3



Golden flower

Black and glue as shown.

4



Champagne metal wire

Cut as shown.

5



Big coppery bead
Golden button

Insert and glue as shown.

6



Glue as shown.


Iron roll



Material List

- 1 Aluminum sheet 15x10mm 1pc (Bag No.2)

1



15
10

Cut as shown.

2



Cut as shown.

3



Paper stick

Roll the aluminum sheet as shown by using the paper stick.

4



Trim as shown.


Bell



Material List

- 1 Brown bell 1pc (Bag No.3)
- 2 Big coppery bead 1pc (Bag No.3)
- 3 Coppery chain 1pc (Bag No.3)
- 4 Brown metal wire L10mm 1pc (Bag No.2)

1



Big coppery bead

Brown bell

Glue as shown.

36



Side view Front view
m x2pcs

Complete 2 pieces as shown.

37



m m

Glue as shown.


38



K41

Glue as shown. Completed.

Mini-house



Material List

- 1 Wood pieces 11pcs
- 2 Golden bead 2pcs (Bag No.3)
- 3 Aluminum sheet 1pc (Bag No.2)
- 4 Paper-cut K3-K6, K8, K9, K19

1



Glue as shown.

2



Paint white as shown.

3



K6

Glue as shown.

4



K3

Glue as shown.

5



B37

Glue as shown.


6



Golden bead

Glue as shown.

7



Aluminum sheet
4 4 10

Fold as shown.

8



Aluminum sheet

Fold the aluminum sheet and glue as shown.

9



Mini-house A
Golden bead

Paint the bead orange and glue.


10



K8
B13

Glue K8 as shown.

11



K9
B11


Glue as shown.

12



B12

Glue as shown.



Glue as shown.



Glue as shown.




Glue as shown.


Chair

Material List


1 Wood pieces	17pcs
2 White fabric	1pc (Bag No.1)
3 Coppery button	1pc (Bag No.3)
4 Coppery eyelet	1pc (Bag No.3)
5 Thick silver metal wire L17mm	1pc (Bag No.2)
6 Black wire L10mm	1pc (Bag No.2)



Cut the white fabric as shown.



Wrap and glue.




Wrap and glue.



Wrap and glue.



Cut the fabric based on B40 as shown.



Wrap around B40 and glue.



Front view

Glue as shown.



Back view

Glue as shown.




Side view

Glue as shown.



Back view

Glue as shown.



Cut B17 on the red line shown. (1:1 illustration)



Glue as shown.



Final effect.




Completed as shown.

Rack

Material List

- 1 Wood pieces 3pcs



Paint B28 black.



Mix brown pigment and water in a ratio of 1:3, then paint.




Glue as shown.


Frame

Material List


- 1 Wood pieces 2pcs
- 2 Transparent sheet 1pc
- 3 Paper-cut K22, K23




Paint B20 black.




Glue the transparent sheet behind the frame.



Glue K23 behind the transparent sheet.




Mix brown pigment and water in a ratio of 1:3, then paint.



Glue the transparent sheet behind the frame.



Glue K22 behind the transparent sheet.



Cut as shown and fold in half.



Glue as shown.


Hook

Material List


- ① Brown metal wire L15mm 1pc (Bag No.2)
- ② Champagne metal wire L30mm 1pc (Bag No.2)



Cut as shown.



Bend the brown metal wire as shown.



Bend the champagne metal wire as shown.

Clock

Material List

- ① Wood pieces 4pcs
- ② Paper-cut K7



Paint B45 black.




Glue K7 onto B45.



Paint B33 blue and glue.



Paint the side black as shown.



Glue as shown.



Paint B44 black.



Glue as shown.



Glue as shown.



Paint orange as shown.



Glue as shown.



Glue as shown.




Glue as shown.



Glue as shown.




Glue as shown.



Cut as shown.



Glue as shown.



Cut as shown.



Cut off the black coat in specific length as shown. Fix the rest on two ends.



Glue as shown. Completed.

Equipment 1


Material List

- ① Wood pieces 3pcs
- ② Coppery button 1pc (Bag No.3)
- ③ Paper-cut K20




Glue as shown.


2 Coppery button




3




4




5



6



7



Paint black and glue as shown.

Fold K20 as shown.


Glue as shown.

Glue as shown.

Glue as shown. Completed.

Glue as shown.

Equipment 2



1-B27


K14

K21


Material List

- 1 Wood pieces 1pc
- 2 Paper-cut K14, K21


1



2



3




Paint black.

Roll K14 and glue as shown. Glue K21 onto both ends.

Glue as shown.

House model



1-B9

1-B10

1-B62

1-B67

1-B68

1-B69

K24

K26

K27

Material List

- 1 Wood pieces 6pcs
- 2 Golden paper 20×10mm 1pc (Bag No.1)
- 3 Paper-cut K24, K26-K28

1



2



3




Glue as shown. (Glue B62 onto the middle of B68 as shown.)


Paint white as shown.

Glue as shown.


4



5



6



Glue K24 as shown. (Trim the excessive.)

Cut the golden paper as shown.

Glue as shown.


Tool




Material List

- 1 Wood pieces 2pcs
- 2 Paper stick L14mm 1pc (Bag No.2)
- 3 Silver steel wire L100mm 1pc (Bag No.2)
- 4 Black wire L15mm 1pc (Bag No.2)
- 5 Golden paper 10×10mm 1pc (Bag No.1)
- 6 Aluminum sheet 20×15mm 1pc (Bag No.2)
- 7 Paper-cut K25


1




2




3




4



5



6



Cut the paper stick and glue as shown.

Paint brown as shown.


Bend the L100mm silver steel wire as shown by using the remaining paper stick.

Cut as shown.


Cut and mark as shown.

Glue as shown.


4



5



6




Cut as shown.


Cut and mark as shown.

Glue as shown.


7



8



9



Cut as shown.

Cut the aluminum sheet as shown.

Glue as shown.

Small jar



1



Material List

- 1 Transparent jar 1pc (Bag No.3)
- 2 Champagne metal wire L20mm 1pc (Bag No.2)
- 3 Paper-cut K29

Glue as shown.