

# BIKE TRAILER

## ASSEMBLY INSTRUCTIONS

Keycode:43181964



1. Open the frames



(Pic1)



(Pic2)

2. Insert the buckle as Pic2



(Pic1)




(Pic2)

3. Install the snap at the bottom of the backrest as pic2



(Pic1)



(Pic2)

4. Attach the wheels as pic2, and insert the safety pin to ensure the wheels are firmly engaged



(Pic1)



(Pic2)


5. Release the tow bar by removing the safety pin from lower to upper hole, and fasten it with correct way



(Pic1)



(Pic2)



(Pic2-1)



(Pic3)

6. Install the cover with snaps and velcon closures around the hood, which marked with red arrows(pic2 and pic2-1), after that tighten the tie of pic3



Brake function: wrap the strap around the wheel then tighten the D-ring to prevent the slide



# BICYCLE TRAILER MODE



**Pls note:5-point harness buckle, adjustable, for two babies with A, one baby with B**



**(Pic4)**



**(Pic1)**



**(Pic2)**



**(Pic3)**

**7.Remove the safety pin,get the hitch(red arrow 2 of pic1), then tighten it on the left of bike's rear wheel axle(pic2), insert flex connector of tow bar(pic3), aligned the holes,and insert the safety pin, finally wrap the strap around the frame of bike twice and latch to the D-ring on the tow bar (pic4)**

## **WARNING:**

Failure to comply with the instructions and warnings in this manual could result in serious injury or death of the passenger or rider.

Never leave the child unattended.

Ensure that all locking devices are engaged before use.

To avoid injury ensure that the child is kept away when unfolding or folding this product.

Do not let the child play with the product.

Always use the restraint system.

Do not install a car seat or any other seating device in the product.

When using double trailer with one child, always seat the child in the middle position.

Make sure children can't put fingers, clothing, toys or shoelaces into the wheel spokes or any other moving parts.

Do not expose the bike trailer to prolonged time in the sun or rain. Store this product in a cool and dry place.

Parcels or accessory items, or both, placed on the unit may cause the unit to become unstable.

Unstable hazardous conditions may exist if package carry accessories are added onto the product.

Check that the bike trailer body is correctly engaged before use.

This trailer is only suitable for children aged 12 months - 6 years old.

Maximum weight limit is 100lbs(45 kg).

Do not over-inflate the tires. Failure to comply with the rated tire sidewall pressure may lead to explosion of the tire and possible injury.

Not to be used on sloped driveways, inclines and public highways or uneven surfaces.

Do not maneuver over stairs or other obstacles while your child is inside.

It's prohibited to use the spare parts not provided by the manufacture.

## **When used as a bicycle trailer:**

It is recommended that a qualified bicycle mechanic does a safety check of the towing bicycle before attaching the trailer.

Before each ride, be sure the trailer does not interfere with braking, pedalling or steering of the bicycle.

Always comply with the regulations when using the trailer on public roadways.

Never ride a bicycle at night without adequate lighting.

Obey all local legal requirements for lighting.

The red reflectors that came with the trailer must remain attached and visible on the rear of the trailer at all times.

If you need to come to stop for any reason, such as to check on your child, to make adjustments or to address a flat tire, be sure to pull off of the road completely.

When using your trailer, you are towing extra weight and a bigger vehicle. You must allow more time for braking, slowing, stopping and starting, especially when riding downhill, and allow more room for turns, corners, and passageways.

Experiment with the loaded trailer in an uncongested area until you become familiar with how your bike handles towing a trailer.

Avoid rocks, curbs, hard braking and sudden swerving. Avoid riding over obstacles with one wheel, as this may cause the trailer to tip over.

Children must be able to sit upright without support and have adequate neck strength to support their heads before being carried in a trailer. Consult a pediatrician to determine if a child is of sufficient developmental age to be carried in a bicycle trailer.

Always ride with the cover down to protect children from flying debris.

Passengers must wear a bicycle helmet that meets applicable safety standards.

The rider of the bicycle must be at least 16 years old.

Recommended speed limits:

-15 mph(24 km/h) on smooth, straight roads.

-5 mph(8 km/h) when turning or on uneven roads.

MADE IN CHINA